

Installation Instructions

Hickory Hammock

Part # AP006V2



ID SCULPTURE

PLAY. CLIMB. EXPLORE.

591 South Boulevard Street

Gunnison, Colorado 81230

info@idsculpture.com

970-641-1747

Specifications: Hickory Hammock

- Material: Concrete with Structural Steel
- Approximate Installed Size (Assembly): 10'-9" x 9'-7" x 1'-7" Tall
- Approximate Uninstalled Size (Each Stepping Form): 18" DIA x 2'-7" Tall
- Approximate Weight: 700 lbs (Each Stepping Form)
- Approximate Total Shipping Weight: (Palletized) 4,300 lbs
- Maximum Fall Height: 1'-7" (Assumes 1' of Surfacing)
- Age Group: 2-5 Years Old

Required Parts (included):


- Concrete Stumps: 6ct
- Hickory Hammock Net
- 5/8"X 6" SS Wedge Anchor: 24ct
- "Hickory Hammock Layout" Drawing Set

Recommended Equipment (not included):


- Hammer Drill
- 5/8"x 10" Concrete Drill Bit
- Hammer
- 15/16" Wrench
- 6' Lifting Straps: 2ct
- Large Adjustable Crescent Wrench
- Lift: Forklift or Skidsteer 2,000 lb Capacity

Important Notes:

- *Warning: Installation over a hard surface such as asphalt, or packed earth may result in serious injury or death from falls.*
- *It is the responsibility of the installer to ensure all components are installed in compliance with ASTM F-1487.*
- *All site built footings should be allowed to cure for a minimum of 48 hours prior to installation.*



Typical Wedge Anchor Installation



Section

Installation Instructions

Hickory Hammock

Part # APoo6V2



591 South Boulevard Street
Gunnison, Colorado 81230
info@idsculpture.com
970-641-1747


PRE-INSTALL CHECKLIST

Please review prior to ordering and installing ID Sculpture products.

- ☐ 1. Verify that you have the recommended lifting equipment to unload and install your component, as specified by the installation instructions. Please check the installation instructions for the weight of each component and shipping dimensions.
- ☐ 2. Develop a proper plan to access the site and control access prior to opening.
- ☐ 3. Call your local utilities to locate any potential existing below grade equipment?
- ☐ 4. FOR ALL SCULPTURES: Verify you have accounted for adjustments to the footing depth based on your choice of safety surfacing material. Footing depth must be adjusted to compensate for the depth/thickness requirements of the selected safety surfacing (*see diagrams below*). Layout drawings show the uninstalled dimensions of the component. If you require a modification to a standard component, please notify ID Sculpture when placing your order. *Additional charges may apply.*



*Critical Fall Height (CFH)



- ☐ 5. Verify that you have installed any required footings prior to the arrival of your sculptures. Please note, footings should be allowed to cure for a minimum of 7 days.

Important Safety Note:

Please install and maintain adequate protective surfacing under and around your equipment. Never let children play on the equipment before protective surfacing is installed. Please consult ASTM F1487 for more information.

Installation Instructions

Hickory Hammock

Part # APoo6V2



591 South Boulevard Street
Gunnison, Colorado 81230
info@idsculpture.com
970-641-1747

Installation:

1. Locate and construct the footer based on the provided layout plan drawing.
 2. Attach 2 lifting straps securely wrapped as a "choke" around the middle of each stepping form at each side. Make sure that the lifting straps are securely hitched around the sculpture.
 3. Lift the sculptures using an appropriate forklift or skid steer taking care to equalize the load on straps. The use of a hand truck or dolly with 2 workers can also be sufficient. Take care that the strap does not bear on any rope connections.
 4. Set the pieces in place on the poured footing and verify layout and all use zones as required by ASTM 1487.
 5. Connect sculpture rope to the concrete stumps with provided Igloo rope connectors & connection pin (6). Tighten the clevis screws. Please note screws are pretreated with thread lock compound.
 6. Reposition the stumps as necessary to ensure proper tension of the net.
- *** Never install any rope component taut, some slack should always be present. ***
7. Drill through the holes in the mounting plates to a minimum depth of 5".
 8. Use a brush and compressed air to clean the holes.
 9. Install the stainless steel wedge anchors (4 per concrete stepping form) and tighten.
 10. Install resilient surfacing material in accordance with layout guidelines, and ASTM standards.



Female Threaded Connection



Installed Connector


Installation Instructions

Hickory Hammock

Part # APoo6V2



591 South Boulevard Street
Gunnison, Colorado 81230
info@idsculpture.com
970-641-1747



Footings Locate Diagram